




# **IMPERIO**

## **Electric Kettle**

### **Instruction Manual**



Information in this manual is subject  
to changes without notice.  
Edition: 2026/01

Please read the manual carefully before using the product

## READ THESE INSTRUCTIONS CAREFULLY BEFORE USAGE

**WARNING:** To avoid injury, electric shock, or fire caused by improper use, carefully read and follow all safety instructions below.

1. Incorrect operation and improper handling can lead to faults on the appliance and may cause injuries to the user.
2. Improper usage or incorrect handling will void the warranty, and no liability can be accepted for any damages that may occur.
3. Before connecting the plug to the socket, please ensure that the electric current and mains voltage are suitable for use. You can check the power rating/nameplate on the underside of the appliance.
4. Place the kettle base away from damp surface and avoid water splashes.
5. Do not immerse the unit or mains plug in the water or other liquids. This will cause injuries or even death due to electric shock. However, if this should occur, remove the mains plug immediately and have the unit checked by a qualified electrical service provider before using it again.
6. Do not operate the appliance if the power cable or the power plug shows signs of damage. If the appliance has been dropped and damaged, do not use until the appliance has been checked and repaired.
7. Ensure that the power cable does not hang over sharp edges to avoid damage. Keep it away from hot objects and open flames. Only pull it out of the socket by the plug and not by the cable.
8. Place the appliance on a stable level and heat-resistant surface, away from hot objects (e.g. hotplates) and naked flames.
9. You should never leave the appliance unattended during use.
10. Keep the appliance away from children to prevent hazards and injuries.
11. Use the kettle only with the base supplied. Do not use the base for any other purposes.
12. Never remove the kettle from its base while in operation. Always switch off the appliance first.
13. The kettle is for heating water only and not for other types of liquids. Do not use it for cooking.
14. Always ensure that the lid is closed when pouring the water out. Beware of scalding.
15. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly Qualified persons to avoid a hazard.
16. This appliance is intended to be used in household and similar applications such as:
  - staff kitchen areas in shops, offices and other working environments
  - farmhouses;
  - By clients in hotels, motels and other residential type environments
  - Bed and breakfast type environments.
17. Ensure that the appliance is switched off before removing it from its stand
18. If the kettle is overfilled, boiling water may be ejected.
19. The appliance is not to be used by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction.
20. Ensure that the kettle is switched off before removing it from the power base.

**CAUTION:** Ensure that the kettle is switched off before removing it from its base.



This marking indicates that this appliance should not be disposed with other household wastes. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources.

## Product Overview

The Electric Kettle is a convenient and efficient appliance designed for fast water heating in homes, hotels, and offices. Built with safety, durability, and ease of use in mind, it allows users to quickly boil water for beverages and instant food preparation.

## TECHNICAL SPECIFICATIONS

Supply voltage: 220-240V, 50/60Hz

Product code: 8662525/8662526


Power: 1350W

Capacity: 1.0 liters


Material of kettle interior: SUS304

Double wall: Yes

360° power base



## Functions

<p>Kettle On/Off switch (Located below handle) 0= Off I= ON</p>	
<p>Lid Open Button/Switch</p>	<p>Press the lid button to open kettle lid</p>
<p>Auto Shut-off &amp; Boil Dry Protection</p>	<p>Automatically turns off when water reaches boiling point or when kettle is empty</p>
<p>Durable Construction</p>	<p>Inner pot made of SS 304</p>
<p>360° Rotational Base</p>	<p>Enables easy lifting and placement from any angle</p>
<p>Ergonomic Design</p>	<p>Cool touch(double wall) body and easy-pour spout ensure safe handling</p>
<p>Water Level Indicator Interior (Min / Max)</p>	<p>Allow users to measure water quantity</p>

### Power On/Off

1. To turn **ON**, press the power switch down.
2. The indicator light will illuminate, showing that the kettle is heating.
3. The kettle will automatically switch **OFF** once the water reaches boiling point.

### Opening & Closing of Lid

1. To open the lid, press the lid open switch.
2. To close the lid, gently push it down until it locks securely in place.

### Shutdown

1. After use, ensure the power switch is in the 'OFF' (0) position.
2. Unplug the unit from the power socket and allow it to cool before storing.

## OPERATION

### 1.Power Connection

Wind out the mains cord through the opening in the base. Do not overextend. Connect the power plug to a suitable mains socket. Place the base on a flat, stable surface.

### 2.Filling with Water

Open the lid by pressing the lid release button, then pour in the desired amount of water. Check the water level indicator inside the kettle and **do not exceed the "MAX" mark.**

### 3.Closing the Lid

Close the lid by pressing it down until it clicks securely. Ensure the kettle is switched **OFF** before placing it on the base.

### 4.Starting Operation

Press the power switch down to the "I" position. The kettle will begin to heat, and the indicator light will turn on.

### 5.Automatic Shut-Off

When the water reaches boiling point, the kettle will automatically switch **OFF**, and the indicator light will go out.

### 6.Pouring

You may pour hot water directly through the spout without opening the lid.

### 7.Manual Shut-Off / Interruption

To stop or interrupt boiling, push the power switch up to the "O" position before removing the kettle from its base.

FAULT	SOLUTION
Kettle unable to power up	Check that the main supply is switched on
	Ensure the power plug is properly connected
	Ensure the kettle switch is at the 'On' position
	Ensure the kettle has cooled sufficiently before turning it on again, as it may have overheated.

**Note:**

This appliance comes with a safety device which automatically switches off the heater element if the appliance is empty of water if it boils dry. In this case, let the appliance cool down completely before filling with water again.

**STORAGE**

1. Cool Down: Ensure the kettle is completely cooled and unplugged before storage.
2. Empty Water: Always empty any remaining water from the kettle and the base.
3. Clean: Wipe the interior and exterior with a dry or slightly damp cloth. Avoid immersing the base in water.
4. Store Safely: Store the kettle in a dry, well-ventilated area. Keep the cord neatly coiled to prevent damage.

**CARE & MAINTENANCE**

1. Unplug & Cool: Always unplug the kettle from the mains and let it cool completely before cleaning.
2. Wipe Clean: Clean the exterior and the base with a soft, damp cloth. Do not immerse in water.
3. Descale Regularly: Use a suitable descaling agent and follow the product instructions to remove limescale.
4. Avoid Abrasives: Do not use metal or hard objects to clean the kettle, as this may cause damage or rust.

**Warranty**

A faulty connection or any damage resulting from the wrong usage, or which is in contradiction to the instructions in this leaflet will render the warranty void.